



Doc Size 2.438 bytes

**IBM Dealer Confidential**  
**Service Hints & Tips**

Document Number  
JBAR-3QNPUC

---

**IBM PS/2 - Hangs with XGA, SCSI and Image Adapter/A installed**

**Symptom:**

Any 8 slot PS/2 may fail to complete POST when certain Adapters are installed in specific slots. This may result in a system hang during POST.

**Problem Isolation Aids:**

None.

**Fix:**

If an XGA or XGA-2 adapter installed in slot 5, an Image Adapter/A in slot 7, and a SCSI adapter in slot 8, and you are observing hangs during POST, relocate the SCSI adapter to another slot. If the problem still exists after moving the adapter, normal problem determination procedures should be followed.

**SAS KEYWORDS :**

PSY2	PSY2ADPT	PSY2MISC	P/N87F4774
P/N96F7657	P/N06G8224	87F4774	96F7657
06G8224	HUNG	STOPS	D/T8565
D/T8560	D/T9585	D/T8595	D/T9595

**Document Information:**

Search Keywords  
Hint Category **Lock-up/Hang, Retain, SCSI, Video**  
Date Created **23.03.94**  
Last Updated **20.05.98**  
Revision Date **19.05.2000**  
Brand **IBM PC**  
Product Family **PS/2**  
Machine Type **8560, 8580, 8595, 9595**  
Model **all**  
TypeModel  
Retain Tip (if applicable) **H122316**  
Reverse Doclinks and Admin Purposes