



IBM Dealer Confidential

GSMH-3A8FDM

Doc Size 2.114 bytes

## Service Hints & Tips

---

### IBM PS/2 - Memory limitations (8570, 8580)

#### Service Information:

8570/80 systems support a maximum of 16MB of memory. Installing more than 16MB may cause unexpected results with diagnostics and/or machine operation. The 8570/80 diags are not intended to operate in any machine with more than 16MB installed. False errors may be generated.

If errors or unexpected results are encountered, the amount of memory that exceeds 16MB must be removed before performing Problem Determination (PD), running diagnostics, or replacing any parts. Additional information is contained in the IBM Personal System/2 Hardware Maintenance Manual (HMM) (S52G-9971.)

#### SAS KEYWORDS:

PSY2	MEGABYTE	PSY2MEM	16 MB
LIMIT	REBOOT	POST	PSY2ERR
PSY2DIAG	RE-BOOT	BOOT	D/T8570

---

#### Document Information:

##### Search Keywords

Hint Category	<b>Retain, Memory</b>
Date Created	<b>11.08.95</b>
Last Updated	<b>08.05.98</b>
Revision Date	<b>27.04.99</b>
Brand	<b>IBM PC</b>
Product Family	<b>PS/2</b>
Machine Type	<b>8570, 8580</b>
Model	<b>all</b>
TypeModel	
Retain Tip (if applicable)	<b>H121028</b>
Reverse Doclinks and Admin Purposes	